CompactFlash® Adapter Quick Start Guide

Introduction

Transcend's CompactFlash PCMCIA Adapter allows CompactFlash cards to be used in any device that has a PCMCIA slot. The Adapter is compatible with CompactFlash cards that comply with the CompactFlash Association's Type I specifications, including Transcend-brand CompactFlash cards . The instructions on this page provide general installation and handling information for the Adapter, which should be used in conjunction with the Owner's Manual for your notebook or device.

Installation Procedure



► CompactFlash Adapter

1. The Adapter and CompactFlash cards can be used in notebooks or any device with a PCMCIA slot to store, copy, and share information just like a miniature hard drive.
2. With the Transcend logo facing up, install a CompactFlash card into the Adapter by aligning the notches on the card with those on the Adapter.
3. Insert the adapter completely into the PCMCIA (also known as PC Card) slot on your notebook computer or device and firmly push it into place.
4. In Windows, when you double-click on "My Computer", you should see the card listed as a removable drive. In Mac OS X 10.0 or later, an icon representing the card will appear on the desktop.

⚠ *CAUTION*

Never remove the Adapter from the PCMCIA port of the device, or the CompactFlash Card from the Adapter, while the CompactFlash Card is being accessed (reading, writing, erasing, etc.). This could result in corruption or erasure of data, as well as damage to the CompactFlash Card.