Upgrading Firmware

Use this function to keep your StoreJet Cloud device up-to-date with the latest firmware version. When a newer version is released, go to www.transcendinfo.com/downloads to download it.

Note: To prevent data loss, it is recommended that you backup your data to another location before upgrading the firmware of your StoreJet Cloud.

1. Download the .bin file and connect StoreJet Cloud to your computer.
2. Copy the .bin file to StoreJet Cloud's root directory.
3. Disconnect StoreJet Cloud from your computer.
4. Power on StoreJet Cloud and wait for wireless connectivity to your iOS device.
5. Launch the StoreJet Cloud App on your iOS device.
6. Press the settings button from the folder directory and then press **Firmware Upgrade**.
7. To confirm firmware upgrade, press **OK**.
8. StoreJet Cloud will complete firmware upgrade and reboot after 180 seconds.



IMPORTANT: Please do NOT interrupt firmware upgrade. Any interruption during the process may cause unexpected results.