Photo Frame Firmware Upgrade Utility



(v1.2)

Contents

Hardware Requirements 3

Supported Operating Systems 3

How to use the utility? 3

1. Use a USB cable to connect one Photo Frame to a PC first. 3
2. Hold on pressing left button. Then plug the adaptor. 3
3. Release the button if the PC detects the photo frame. 4
4. Double-clicking on Execute file to begin. 4
5. Please select a Produce Name. 5
6. Please input the serial number of Photo Frame. 5
7. Click “upgrade” button to start. 6
8. Waiting for upgrade finish. 6
9. Upgrade complete. 7

Hardware Requirements

1. Transcend Photo Frame
2. Desktop or Notebook computer with an available USB port

Supported Operating Systems

Photo Frame Firmware Upgrade Utility supports the following operating system.

- Windows XP (32bit)
- Windows Vista (32bit)
- Windows 7 (32bit)

How to use the utility?

1. Use a USB cable to connect one Photo Frame to a PC first.



2. Hold on pressing left button. Then plug the adaptor.





3. Release the button if the PC detects the photo frame.



4. Double-clicking on Execute file to begin.



Press “Continue” to install the drivers



5. Please select a Produce Name.



6. Please input the serial number of Photo Frame.



7. Click “upgrade” button to start.



8. Waiting for upgrade finish.



(Please do not unplug the Photo Frame)

9. Upgrade complete.



(Please reboot the Photo Frame.)